

Printing Problem

Stringy/Hairy Pad Printed Image

<i>Pad Related Possibilities</i>	<i>Corrective Action</i>
Worn out silicone pad--only releases partial image.	Replace with a new silicone pad.
<i>Ink Related Possibilities</i>	<i>Corrective Action</i>
Ink viscosity is too thick, causing a dry spot in the center.	Add thinner or retarder. Speed up machine cycle.
<i>Cliche' Related Possibilities</i>	<i>Corrective Action</i>
Cliche is etched too deep.	Remake cliche with longer screen exposure.

Troubleshooting Tip

Although not a common problem with Printex's Visprox inks, this problem exists with other pad printing inks in the market place. If you are experiencing these problems please feel free to call our technical support team at (800) 982-1928 for assistance.